



APEasyPower V1.2.0 Power Setting Instructions

APsystems EMEA

Karspeldreef 8, 1101 CJ
Amsterdam
Phone: +31 (0)85 3018499
Email: info.emea@APsystems.com
emea.APsystems.com

APsystems France

22 avenue Lionel Terray
69330 Jonage
France
Phone: 031-10-2582670
Email: info.emea@APsystems.com
emea.APsystems.com

© All Rights Reserved

Introduction


AP EasyPower v1.2.0 Update

- Added maximum power setting function for EZ1-M (power setting between 600W-800W)


Maximum Power Setting

1. Enter the maximum power setting page

- ▶ Logging into AP EasyPower and enter the device list , click the device that needs to set its maximum power




- ▶ Click the settings button in the upper right corner of the page and click into the device settings page



-
- ▶ Click “Maximum Power” into maximum power setting page

Settings



Device ID
E07000C [blurred]

Alias
[blurred]

>

Model Name EZ1

Bluetooth >


Maximum Power >

Remove Device

2. Set maximum power

- ▶ After entering the settings page, you can view the current maximum power and click to set it.

Drag the slider to set the maximum power, between 600W-800W. You can also click the "+" and "-" buttons to adjust, and click "OK" to send it to the device.



Set maximum power

